



LS300W firmware update_130328 version

Caution:

1. Before update, check first if the firmware version is "LS300W130328". If yes, there's no need to update.
2. Reset internal settings since it would be fully restored to Factory Default after update.
3. Please immediately call toll-free number: 0800-880865 while you encounter the machine fail to be updated or other related issues.

Updates:

Add:

- ※ In recording mode, long press the "mode" button, it allows to quick switch Sound Recording On/Off.
- ※ Main screen - Sound recording On/Off icons

Remove:

- ※ Camera mode - "Quick View" menu

Modify:

- ※ Some of wording changes in Chinese Menu.
- ※ In night shot, more bright in dark side.

Upgrade Steps:

1. Download and decompress the firmware file ([LS300W_130328.rar](#)).
2. Please have the updated file to be copied to the root directory of your memory card.
3. Plug in the power, the Car DVR will automatically start. (If you boot from built-in battery, it may cause update failed by an electrical power outage.)
4. When you operate the machine, it will update automatically. With full grey screen in update progress, please wait for around 30s for its auto-reboot.
5. Press format or delete the firmware file from the memory card (avoid update loops). Update complete!